AECO 30 IP DMX Chart

适用于固件版本 V2.1 及以上

CHANNEL				VALUE	FUNCTION
43ch	34ch	32ch	23ch		
1	1	1	1	000-255	PAN 0°→540°
2	2	2	2	000-255	PAN FINE
3	3	3	3	000-255	TILT 0°→270°
4	4	4	4	000-255	TILT FINE
5	5	5	5	000-255	PAN/TILT SPEED Fast to Slow
6	6	6	6	000-007 008-255	GREEN CORRECTION Close Open
7	7	7	7	000-255	CYAN 0%→100%
8	8	8	8	000-255	MAGENTA 0%→100%
9	9	9	9	000-255	YELLOW 0%→100%
10	10	10	10	000-255	CTO 0%→100%
11	11	11	11	000-007 008-018 019-029 030-040 041-051 052-063 064-068 069-073 074-078 079-083 084-088 089-093 094-098 099-103 104-108 109-113 114-118 119-123 124-127 128-189 190-193 194-255	COLOR WHEEL 1 Open Color 1 Color 2 Color 3 Color 4 Color 5 Open Open + Color 1 Color 1 Color 1 + Color 2 Color 2 Color 2 + Color 3 Color 3 Color 3 + Color 4 Color 4 Color 4 + Color 5 Color 5 Color 5 + Open Open Counter-Clockwise Rotation, Fast to Slow Stop Clockwise Rotation, Slow to Fast

适用于固件版本 V2.1 及以上

12	12	12	12		**COLOR WHEEL 2**
				000-007	Open
				008-021	CTB
				022-035	Color 1
				036-048	Color 2
				049-063	Reserved
				064-069	Open
				070-075	Open + CTB
				076-081	CTB
				082-087	CTB + Color 1
				088-093	Color 1
				094-099	Color 1 + Color 2
				100-105	Color 2
				106-111	Color 2 + Green Correction
				112-117	Green Correction
				118-123	Green Correction + Open
				124-127	Open
				128-189	Counter-Clockwise Rotation, Fast to Slow
				190-193	Stop
				194-255	Clockwise Rotation, Slow to Fast
13	13				**GOBO WHEEL 1**
				000-007	Open
				008-016	Gobo 1
				017-025	Gobo 2
				026-034	Gobo 3
				035-043	Gobo 4
				044-052	Gobo 5
				053-063	Gobo 6
				064-073	Gobo 1 Shaking, Slow to Fast
				074-083	Gobo 2 Shaking, Slow to Fast
				084-093	Gobo 3 Shaking, Slow to Fast
				094-103	Gobo 4 Shaking, Slow to Fast
				104-113	Gobo 5 Shaking, Slow to Fast
				114-127	Gobo 6 Shaking, Slow to Fast
				128-189	Counter-Clockwise Rotation, Fast to Slow
				190-193	Stop
				194-255	Clockwise Rotation, Slow to Fast
14	14				**R-GOBO WHEEL 1**
				000-127	Index 0°→360°
				128-189	Counter-Clockwise Rotation, Fast to Slow
				190-193	Stop
				194-255	Clockwise Rotation, Slow to Fast
15	15				**R-GOBO WHEEL 1 FINE**
				000-255	0%→100%
16	16				**GOBO WHEEL 2**

				000-007	Open
				008-016	Gobo 1
				017-025	Gobo 2
				026-034	Gobo 3
				035-043	Gobo 4
				044-052	Gobo 5
				053-063	Gobo 6
				064-073	Gobo 1 Shaking, Slow to Fast
				074-083	Gobo 2 Shaking, Slow to Fast
				084-093	Gobo 3 Shaking, Slow to Fast
				094-103	Gobo 4 Shaking, Slow to Fast
				104-113	Gobo 5 Shaking, Slow to Fast
				114-127	Gobo 6 Shaking, Slow to Fast
				128-189	Counter-Clockwise Rotation, Fast to Slow
				190-193	Stop
				194-255	Clockwise Rotation, Slow to Fast
17	**17**				**R-GOBO WHEEL 2**
				000-127	Index 0°→360°
				128-189	Counter-Clockwise Rotation, Fast to Slow
				190-193	Stop
				194-255	Clockwise Rotation, Slow to Fast
18	**18**				**R-GOBO WHEEL 2 FINE**
				000-255	0%→100%
19	**19**				**ANIMATION**
				000-007	Open
				008-129	Counter-Clockwise Rotation, Fast to Slow
				130-133	Stop
				134-255	Clockwise Rotation, Slow to Fast
20	**20**	**13**	**13**		**IRIS**
				000-255	100%→0%
21	**21**				**PRISM 1 (4-facet circular prism)**
				000-007	Close
				008-255	Open
22	**22**				**R-PRISM 1**
				000-127	Index 0°→360°
				128-189	Clockwise Rotation, Fast to Slow
				190-193	Stop
				194-255	Counter-Clockwise Rotation, Slow to Fast
23	**23**				**PRISM 2 (4-facet linear prism)**
				000-007	Close
				008-255	Open
24	**24**				**R-PRISM 2**
				000-127	Index 0°→360°
				128-189	Clockwise Rotation, Fast to Slow
				190-193	Stop

适用于固件版本 V2.1 及以上

				194-255	Counter-Clockwise Rotation, Slow to Fast
25	25	14	14	000-255	**FROST 1 (Soft)** 0%→100%
26	26	15	15	000-255	**FROST 2 (Heavy)** 0%→100%
27	27	16	16	000-255	**ZOOM** Wide→Narrow
28	28	17	17	000-255	**ZOOM FINE**
29	29	18	18	000-255	**FOCUS** 0%→100%
30	30	19	19	000-255	**FOCUS FINE**
31	31	20	20	**STROBE** 000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	 Close Open Strobe from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Random Strobe from Slow to Fast Open
32	32	21	21	000-255	**DIMMER** 0%→100%
33	33	22	22	000-255	**DIMMER FINE**
34		23		000-255	**BLADE** 0°→180°
35		24		000-255	**BLADE DW 1** 0%→100%
36		25		000-255	**BLADE DW 2** 0%→100%
37		26		000-255	**BLADE UP 1** 0%→100%
38		27		000-255	**BLADE UP 2** 0%→100%
39		28		000-255	**BLADE LF 1** 0%→100%
40		29		000-255	**BLADE LF 2** 0%→100%
41		30		000-255	**BLADE RG 1** 0%→100%
42		31		000-255	**BLADE RG 2** 0%→100%

适用于固件版本 V2.1 及以上

					FUNCTION
					(To activate following functions, stop in DMX value for at least 3 seconds.)
				000-009	Null
				010-019	Blade Mode: Mode 1 (Not available on 34ch & 23ch)
				020-029	Blade Mode: Mode 2 (Not available on 34ch & 23ch)
				030-039	Dimmer Curve Square Law
				040-049	Dimmer Curve Inv Square Law
				050-059	Dimmer Curve Linear
				060-069	Dimmer Curve S
				070-079	Fan Mode: Auto
				080-089	Fan Mode: Quiet
				090-099	Fan Mode: Super Quiet
				100-109	Light Source
				110-119	Light Source
				120-122	Null
				123	900Hz
				124	1000Hz
				125	1100Hz
				126	1200Hz
				127	1300Hz
				128	1400Hz
43	34	32	23	129	1500Hz
				130	2500Hz
				131	4000Hz
				132	5000Hz
				133	6000Hz
				134	10KHz
				135	15KHz
				136	20KHz
				137	25KHz
				138-139	Null
				140-149	Reset Pan/Tilt
				150-159	Reset Effect
				180-199	Null
				200-209	Reset All
				210-219	Dimmer Speed Fast
				220-229	Dimmer Speed Smooth
				230-231	Gobo Short Cut: Enable (Not available on 32ch & 23ch)
				232-233	Gobo Short Cut: Disable (Not available on 32ch & 23ch)
				234-235	Color Short Cut: Enable
				236-237	Color Short Cut: Disable
				238-239	CTB Compensate: Enable
				240-241	CTB Compensate: Disable
				242-243	Sun Protection Mode: On
				244-245	Sun Protection Mode: Off

				246-255	Null