XP 300 BEAM IP DMX Chart

适用于固件版本 V1.0 及以上

Channel	Function	Value	Percent/Setting
25 CH			
1	PAN	000-255	0~100%（0 °~540 °）
2	PAN FINE	000-255	
3	TILT	000-255	0~100%（0 °~270 °）
4	TILT FINE	000-255	
5	PAN/TILT SPEED	000-255	Fast -> Slow
6	CYAN	000-255	0~100%
7	CYAN FINE	000-255	0~100%
8	MAGENTA	000-255	0~100%
9	MAGENTA FINE	000-255	0~100%
10	YELLOW	000-255	0~100%
11	YELLOW FINE	000-255	0~100%
12	CTO	000-255	0~100%
13	COLOR	000-007	Open
		008-011	Color 1
		012-015	Color 2
		016-019	Color 3
		020-023	Color 4
		024-027	Color 5
		028-031	Color 6
		032-035	Color 7
		036-039	Color 8
		040-043	Color 9
		044-047	Color 10
		048-051	Color 11
		052-055	Color 12
		056-059	Color 13
		060-063	Color 14
		064	Open

适用于固件版本 V1.0 及以上

Channel	Function	Value	Percent/Setting
		065	Open+ Color1
		066	Color1
		067	Color1+ Color2
		068	Color2
		069	Color2+ Color3
		070	Color3
		071	Color3+ Color4
		072	Color4
		073	Color4+ Color5
		074	Color5
		075	Color5+ Color6
		076	Color6
		077	Color6+ Color7
		078	Color7
		079	Color7+ Color8
		080	Color8
		081	Color8+ Color9
		082	Color9
		083	Color9+ Color10
		084	Color10
		085	Color10+ Color11
		086	Color11
		087	Color11+ Color12
		088	Color12
		089	Color12+ Color13
		090	Color13
		091	Color13+ Color14
		092	Color14
		093	Color14+Open
		094-127	Open
		128-189	Counter-Clockwise rotation, fast to slow

适用于固件版本 V1.0 及以上

Channel	Function	Value	Percent/Setting
		192-193	Stop
		194-255	Clockwise rotation, slow to fast
14	GOBO	000-007	Open
		008-011	GOBO1
		012-014	GOBO2
		015-018	GOBO3
		019-021	GOBO4
		022-025	GOBO5
		026-028	GOBO6
		029-032	GOBO7
		033-035	GOBO8
		036-039	GOBO9
		040-042	GOBO10
		043-049	GOB11 (effect gobo 1)
		050-056	GOBO12 (effect gobo 2)
		057-063	GOBO13 (effect gobo 3)
		064-067	GOBO1 Shaking Slow->Fast
		068-071	GOBO2 Shaking Slow->Fast
		072-075	GOBO3 Shaking Slow->Fast
		076-079	GOBO4 Shaking Slow->Fast
		080-083	GOBO5 Shaking Slow->Fast
		084-087	GOBO6 Shaking Slow->Fast
		088-091	GOBO7 Shaking Slow->Fast
		092-095	GOBO8 Shaking Slow->Fast
		096-099	GOBO9 Shaking Slow->Fast

适用于固件版本 V1.0 及以上

Channel	Function	Value	Percent/Setting
		100-103	GOBO10 Shaking Slow->Fast
		104-111	GOBO11 (effect gobo 1) Shaking Slow->Fast
		112-119	GOBO12 (effect gobo 2) Shaking Slow->Fast
		120-127	GOBO13 (effect gobo 3)Shaking Slow->Fast
			Counter-Clockwise rotation, fast to slow
		128-189	Stop
		190-193	Clockwise rotation, slow to fast
		194-255	
15	PRISM 1	000-007	Close
		008-255	Open
16	R-PRISM	000-127	Index 0°~360°
		128-189	Clockwise Rotation, Fast to Slow
		190-193	Stop
		194-255	Counter-Clockwise Rotation, Slow to Fast
17	PRISM 2	000-007	Close
		008-255	Open
18	R-PRISM 2	000-127	Index 0°~360°
		128-189	Clockwise Rotation, Fast to Slow
		190-193	Stop
		194-255	Counter-Clockwise Rotation, Slow to Fast
19	FROST	000-007	Close
		008-255	Open
20	FOCUS	000-255	0%~100%
21	FOCUS FINE	000-255	0%~100%
22	STROBE	000-007	Close

适用于固件版本 V1.0 及以上

Channel	Function	Value	Percent/Setting
		008-015	Open
		016-131	Strobe Slow->Fast
		132-139	Open
		140-181	Fast Close Slow Open
		182-189	Open
		190-231	Fast Open Slow Close
		232-239	Open
		240-247	Random Strobe Slow->Fast
		248-255	Open
23	DIMMER	000-255	0%~100%
24	DIMMER FINE	000-255	0%~100%
25	SPECIAL FUNCTION		(To activate following functions,stop in DMX value for at least 3 seconds.) No Function
		000-009	No Function
		010-029	Dimmer Curve Linear
		030-039	Dimmer Curve Square Law
		040-049	Dimmer Curve Inv Square Law
		050-059	Dimmer Curve S
		060-069	No Function
		070-129	Lamp On
		130-139	Reset Pan/Tilt
		140-149	Reset Effect
		150-159	No Function
		160-199	Reset All
		200-209	GOBO Short Cut Enable
		210-211	GOBO Short Cut Disable
		212-213	Color Short Cut Enable
		214-215	Color Short Cut Disable
		216-217	No Function

适用于固件版本 V1.0 及以上

Channel	Function	Value	Percent/Setting
		218-229	Lamp off
		230-239	Sun Protection Mode：On
		240-241	Sun Protection Mode：Off
		242-243	No Function
		244-255	