

CHANNEL			VALUE	FUNCTION
34ch	25ch	29ch		
1	1	1	000-255	PAN 0°→540°
2	2	2	000-255	PAN FINE
3	3	3	000-255	TILT 0°→260°
4	4	4	000-255	TILT FINE
5	5	5	000-255	PAN/TILT SPEED Fast to Slow
6	6	6	000-255	CYAN 0%→100%
7	7	7	000-255	MAGENTA 0%→100%
8	8	8	000-255	YELLOW 0%→100%
9	9	9	000-255	CTO 0%→100%
10	10	10	000-009 010-018 019-027 028-036 037-045 046-063 064-127 128-189 190-193 194-255	COLOR WHEEL Open Color 1 Color 2 Color 3 Color 4 Color 5 Color Wheel Indexing Counter-Clockwise Rotation, Fast to Slow Stop Clockwise Rotation, Slow to Fast
11	11		000-007 008-015 016-023 024-031 032-039 040-047 048-055 056-063	GOBO WHEEL 1 Open Gobo 1 Gobo 2 Gobo 3 Gobo 4 Gobo 5 Gobo 6 Gobo 7

			064-072 073-081 082-090 091-099 100-108 109-117 118-127 128-189 190-193 194-255	Gobo 1 Shaking, Slow to Fast Gobo 2 Shaking, Slow to Fast Gobo 3 Shaking, Slow to Fast Gobo 4 Shaking, Slow to Fast Gobo 5 Shaking, Slow to Fast Gobo 6 Shaking, Slow to Fast Gobo 7 Shaking, Slow to Fast Clockwise Rotation, Fast to Slow Stop Counter-Clockwise Rotation, Slow to Fast
12	12		000-127 128-189 190-193 194-255	R-GOBO WHEEL 1 Index 0°→360° Clockwise Rotation, Fast to Slow Stop Counter-Clockwise Rotation, Slow to Fast
13	13		000-007 008-014 015-021 022-028 029-035 036-042 043-049 050-056 057-063 064-071 072-079 080-087 088-095 096-103 104-111 112-119 120-127 128-189 190-193 194-255	GOBO WHEEL 2 Open Gobo 1 Gobo 2 Gobo 3 Gobo 4 Gobo 5 Gobo 6 Gobo 7 Gobo 8 Gobo 1 Shaking, Slow to Fast Gobo 2 Shaking, Slow to Fast Gobo 3 Shaking, Slow to Fast Gobo 4 Shaking, Slow to Fast Gobo 5 Shaking, Slow to Fast Gobo 6 Shaking, Slow to Fast Gobo 7 Shaking, Slow to Fast Gobo 8 Shaking, Slow to Fast Clockwise Rotation, Fast to Slow Stop Counter-Clockwise Rotation, Slow to Fast
14	14	11	000-255	IRIS 100%→0%
15	15		000-007 008-255	PRISM Close Open

16	16		000-127 128-189 190-193 194-255	R-PRISM Index 0°→360° Clockwise Rotation, Fast to Slow Stop Counter-Clockwise Rotation, Slow to Fast
17	17	12	000-007 008-255	CRI Close Open
18	18	13	000-007 008-255	FROST 1 (Light) Close Open
19	19	14	000-007 008-255	FROST 2 (Heavy) Close Open
20	20	15	000-255	ZOOM Wide→Narrow
21	21	16	000-255	FOCUS 0%→100%
22	22	17	000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE Close Open Strobe from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Random Strobe from Slow to Fast Open
23	23	18	000-255	DIMMER 0%→100%
24	24	19	000-255	DIMMER FINE
25		20	000-255	BLADE 0°-180°
26		21	000-255	BLADE DW 1 0%→100%
27		22	000-255	BLADE DW 2 0%→100%
28		23		BLADE UP 1

			000-255	0%→100%
29		24	000-255	BLADE UP 2 0%→100%
30		25	000-255	BLADE LF 1 0%→100%
31		26	000-255	BLADE LF 2 0%→100%
32		27	000-255	BLADE RG 1 0%→100%
33		28	000-255	BLADE RG 2 0%→100%
34	25	29	000-029 030-039 040-049 050-059 060-069 070-079 080-089 090-099 100-109 110-119 120-179 180-189 190-199 200-209 210-219 220-229 230-255	SPECIAL FUNCTION Null Dimmer Curve Square Law Dimmer Curve Inv Square Law Dimmer Curve Linear Dimmer Curve S Cooling Mode: Auto Cooling Mode: Quiet Null LED Frequency Setting Enable LED Frequency Setting Disable Null Dimmer Speed Fast Dimmer Speed Smooth Reset All Reset Effect Reset Pan/Tilt Null