

CHANNEL					VALUE	FUNCTION
11ch	9ch	8ch	7ch	6ch		
1	1	2	1	1	000-255	RED 0%→100%
2	2	3	2	2	000-255	GREEN 0%→100%
3	3	4	3	3	000-255	BLUE 0%→100%
4	4	5	4	4	000-255	LIME 0%→100%
5	5	6	5		000-007 008-015 016-131 132-139 140-181 182-189 190-231 232-239 240-247 248-255	STROBE Close Open Strobe from Slow to Fast Open Fast Open Slow Close from Slow to Fast Open Slow Open Fast Close from Slow to Fast Open Random Strobe from Slow to Fast Open
6	6	1			000-255	DIMMER 0%→100%
7	7				000-255	DIMMER FINE
8					000 001-004 005-009 010-013 014-018 019-022 023-027 028-031 032-036 037-040 041-045 046-049 050-054 055-058 059-063 064-067 068-072	CTO (8000K-2500K) Close 8000K 7900K 7800K 7700K 7600K 7500K 7400K 7300K 7200K 7100K 7000K 6900K 6800K 6700K 6600K 6500K

					073-076	6400K
					077-081	6300K
					082-085	6200K
					086-090	6100K
					091-094	6000K
					095-099	5900K
					100-103	5800K
					104-108	5700K
					109-112	5600K
					113-117	5500K
					118-121	5400K
					122-126	5300K
					127-130	5200K
					131-135	5100K
					136-139	5000K
					140-144	4900K
					145-148	4800K
					149-153	4700K
					154-157	4600K
					158-162	4500K
					163-166	4400K
					167-171	4300K
					172-175	4200K
					176-180	4100K
					181-184	4000K
					185-189	3900K
					190-193	3800K
					194-198	3700K
					199-202	3600K
					203-207	3500K
					208-211	3400K
					212-216	3300K
					217-220	3200K
					221-225	3100K
					226-229	3000K
					230-234	2900K
					235-238	2800K
					239-243	2700K
					244-247	2600K
					248-255	2500K
9					000-005	COLOR MACRO
					006-008	Open
					009-011	LEE 790-Moroccan Pink
						LEE 157-Pink

					012-014 015-017 018-020 021-023 024-026 027-029 030-032 033-035 036-038 039-041 042-044 045-047 048-050 051-053 054-056 057-059 060-062 063-065 066-068 069-071 072-074 075-077 078-080 081-083 084-086 087-089 090-092 093-095 096-098 99 100-155 156-200 201-255	LEE 332-Special Rose Pink LEE 328-Follies Pink LEE 345-Fuchsia Pink LEE 194-Surprise Pink LEE 181-Congo Blue LEE 071-Tokyo Blue LEE 120-Deep Blue LEE 079-Just Blue LEE 132-Medium Blue LEE 200-Double CT Blue LEE 161-State Blue LEE 201-Full CT Blue LEE 202-Half CT Blue LEE 117-Steel Blue LEE 353-Lighter Blue LEE 118-Light Blue LEE 116-Medium Blue Green LEE 124-Dark Green LEE 139-Primary Green LEE 089-Moss Green LEE 122-Fern Green LEE 738-JAS Green LEE 088-Lime Green LEE 100-Spring Yellow LEE 104-Deep Amber LEE 179-Chrome Orange LEE 105-Orange LEE 021-Gold Amber LEE 778-Millennium Gold LEE 135-Deep Gold Amber Slow Medium Fast
10	8	7	6	5	000-041 042-083 084-127 128-255	FROST Frost 1 Frost 2 Frost 3 0%→100%
11	9	8	7	6	000-029 030-039 040-049	FUNCTION (To activate following functions, stop in DMX value for at least 3 seconds.) Null Dimmer Curve: Linear Dimmer Curve: Square Law

				050-059	Dimmer Curve: Inv SQ Law
				060-069	Dimmer Curve: S Curve
				070-099	Null
				100-109	Led Frequency Setting Enable
				110-119	Led Frequency Setting Disable
				120-122	Null
				123	900Hz
				124	1000Hz
				125	1100Hz
				126	1200Hz
				127	1300Hz
				128	1400Hz
				129	1500Hz
				130	2500Hz
				131	4000Hz
				132	5000Hz
				133	6000Hz
				134	10000Hz
				135	15000Hz
				136	20000Hz
				137	25000Hz
				138-139	Null
				140-209	Null
				210-219	Dimmer Speed: Fast
				220-229	Dimmer Speed: Smooth
				230-255	Null

3ch (Mode 6):

CHANNEL	VALUE	FUNCTION
1	000-255	WHITE 0%→100%
2	000-255	BLUE 0%→100%
3	000-255	FROST 0%→100%